

WORKCYCLES

APPROACH BRIEF

S special aerodrome procedures

T TAF, QNH, Wind

A aerodrome ELE, CCT HGT, overfly HGT, join PROC

N NOTAMs

CLEARO

C compass/DI align

C configuration flaps/gear

L nav log, fuel log

E engine rpm, fuel mixture

A altimetry, terrain, cloud, VMC, QNH, LSALT

R radio frequency, transponder, navaid, GPS

O orientation, clock/map/ground