

Night VFR

Setup VOR

- G430
 - Press C/V to set frequency COM <-> VLOC
 - Set VOR frequency
 - Listen to NAV1 for morse code
 - CDI button to toggle tracking VLOC <-> GPS
 - G500
 - Press CRS button to set a course
 - Turn knob until green line vertical
 - * current radial indicated
-

This document

- hosted at <https://1007036.gitlab.io/nvfr>
 - source hosted at <https://gitlab.com/1007036/nvfr>
 - last updated at time **2024-09-19 01:43:08 UTC**
 - last updated by user **Tony Morris**
 - revision **cfc3b9153b83ae72f4949781b8012adfbcb03ced3**
 - access control **private**
-

Licence

This work is licenced under a Creative Commons Attribution-NonCommercial-NoDerivs 3.0 Australia License.

<https://creativecommons.org/licenses/by-nc-nd/3.0/au/>

