

radio

YBAF Radio

Taxi & Departure Radio

ATIS 120.9

- **Terminal Information:** Alpha
- **Runway (Number L/R):** 10L
- **Runway Frequency:** 123.6
- **Wind (Direction/Speed):** 120/08
- **Cloud (Qty/Height):** FEW/2500
- **Temperature:** 25
- **QNH:** 1012

-
- *set barometric pressure according to ATIS QNH.*

Taxi Call to Ground 119.9

- **Archer Ground:** archer ground
 - **Callsign:** Lima Delta Oscar
 - **Type:** Cessna 162
 - **Location:** Eastern apron
 - **Dual/Solo/PoB:** Dual
 - **Received ATIS:** received Alpha
 - **Departure (Direction or Circuits):** for departure east
 - **Request:** request taxi
-

Read Back from Ground (119.9)

- **Taxi way:** taxiway Bravo
 - **Specific Instructions:** cross 04R & 04L
 - **Holding Point:** holding point Bravo 5
 - **Runway for Departure:** Runway 10 Left
 - **Call Sign:** Lima Delta Oscar
-

Runway Ready

- **Archer Tower (runway frequency):** archer tower
 - **Call Sign:** Lima Delta Oscar
 - **Ready:** ready
 - **Runway:** 10 Left
 - **Departing (*Direction or Circuits*):** departing east
-

Inbound Radio

ATIS 120.9

- **Terminal Information:** Bravo
- **Runway (*Number L/R*):** 10 Right
- **Runway Frequency:** 118.1
- **Wind (*Direction/Speed*):** 120/08
- **Cloud (*Qty/Height*):** Scattered/3000
- **Temperature:** 26
- **QNH:** 1011

Inbound Call

- *tune to appropriate tower frequency*
- **Archer Tower:** archer tower
- **Call Sign:** Lima Delta Oscar
- **Type:** Cessna 162

- **Location:** Target
- **Maintaining:** Maintaining 1500
- **Inbound:** inbound
- **Received:** received Bravo

Read Back

- **Report:** *report*
- **Specific Point:** Downwind 10 Right
- **Call Sign:** Lima Delta Oscar

Report

- **Archer Tower:** archer tower
- **Call Sign:** Lima Delta Oscar
- **Specific Point:** Downwind 10 Right

Circuit Radio

Downwind Call

- **Call Sign:** Lima Delta Oscar
- **Downwind Runway (L/R):** 10 Right
- **Touch'n'Go/Fullstop:** Fullstop

Read Back

- **Number in Sequence OR Touch'n'Go/Fullstop:** Cleared full stop
- **Runway (L/R):** runway 10 Right
- **Call Sign:** Lima Delta Oscar

After Landing to Ground (119.9)

- **Archer Ground:** archer ground
- **Call Sign:** Lima Delta Oscar
- **Request Taxi for Location:** Request Taxi for Eastern Apron

Read Back

- **Cleared Taxi to Specific Point:** cleared taxi to eastern apron
 - **Call Sign:** Lima Delta Oscar
-

This document

- hosted at <https://1007036.gitlab.io/radio>
 - source hosted at <https://gitlab.com/1007036/radio>
 - last updated at time **2024-06-26 07:46:19 UTC**
 - last updated by user **Tony Morris**
 - revision **ebe04e9305ab942f37657ef3746e6e191914499e**
 - access control **public**
-

Licence

This work is licenced under a Creative Commons Attribution-NonCommercial-NoDerivs 3.0 Australia License.

<https://creativecommons.org/licenses/by-nc-nd/3.0/au/>

